

Recessed ALU housing

ML-ALUR-K-V3



Installation instructions



PLEASE FOLLOW INSTRUCTIONS FOR CORRECT INSTALLATION:

1. Measure and cut the aluminium with the diffuser to the correct size using suitable tools (such as 1mm cutting disc).
2. Pre-drill for your fixings approximately 500mm apart or where suitable.
3. Mark your surface for correct positioning, cut out/recess profile and pre-drilled holes.
4. Install suitable fixings (such as toggles, "wall-mates") and fix through the ALU OR fix directly to ceiling battens/rafters through the ALU.
5. Make sure the ALU interior surface is clean from any substance that may prevent the LED strip from sticking to it. Remove double sided protection from the strip and begin pushing it gently into position.
6. Run the cable from the strip out the end of the profile (through end cap with hole) or drill a hole in the profile and exit out of it.
7. When you are satisfied with the strips position, remove the diffusers protective tape and begin pushing the cover on from one end. We suggest staggering any joints in the ALU for the best visual result.

