

Slim ALU housing

ML-ALUSLM-K-V3



Installation instructions



PLEASE FOLLOW INSTRUCTIONS FOR CORRECT INSTALLATION:

NOTE! This profile is very small and only fits certain LED strip, requires DIRECT solder connections (no connectors) and the diffuser slides in from the end.

1. Measure and cut the aluminium with the diffuser to the correct size using suitable tools (such as 1mm cutting disc).
2. Pre-drill for your fixings approximately 500mm apart or where suitable.
3. Mark your surface for correct positioning and pre-drilled holes.
4. Install suitable fixings (such as toggles, "wall-mates") and fix through the ALU OR fix directly to ceiling battens/rafters through the ALU.
5. Make sure the ALU interior surface is clean from any substance that may prevent the LED strip from sticking to it. Remove double sided protection from the strip and begin pushing it gently into position.
6. Run cables out from strip through the end cap (with hole) or if required through the back of the profile (by drilling a suitable hole).
7. When you are satisfied with the strips position, remove the diffusers protective tape and begin pushing the cover on from one end. We suggest staggering any joints in the ALU for the best visual result.

